



steel screw and seal the screw (not included) with the belowwaterline sealant compound.



Plan the installation

Example of installation



The temperature sensor can be mounted in any location where you want temperature to be monitored. The most common applications are transom mounts — to measure surface water temperature — or in a livewell (when mounting in livewell, mount as far from pump as possible).



- Temperature sensor А
- В Processing unit
- С NMEA 2000 CAN bus backbone
- D Livewell

Overview

The Temperature Sensor converts analog temperature data to NMEA 2000 data format.

A You should read all of the installation instructions before proceeding. Decide where to install all components before drilling any holes in your vessel.



C NMEA 2000 connector



Specifications

Temperature Range between -20 and 80 degrees Celsius. PGNs transmitted 59392 – ISO Acknowledgment 60928 – ISO Address Claim 126996 – Product Information 65285 - Temperature with Instance

Choose Lowrance products if you're looking for a quality marine electronics and navigation.