

IMPORTANT: Since a key is not required to insert the locking insert, it is important that the key and device match by operating the lock (retracting the cams) prior to inserting the device for the first time. Also on older fills, before inserting the lock, check for a ridge around the top of the fill neck and remove with a pen knife if present. If the top of the fill neck does not make a smooth transition to the upper part of the fill, the locking insert will be difficult to insert and more difficult to remove. See diagram 1 below.



1. This device is designed to be used (as supplied) on PERKO® brand fills models 0540, 0541, 0580, 0581, 0582, 0583, 0590, 0591, and 1318. **Note: This device is not to be used as a high security device.**
2. This device can be used on PERKO® brand fills models 0542 and 0543 if the plastic cap retainer system is abandoned. See Instruction #5.
3. To install into a compatible deck fill, press the device (key slot side up) into the throat of the fill. Spring action will retract the cams, which will expand and lock onto the hose bib of the fill when the device is fully inserted. On 0540 through 0591 models, the tab on the top of the device should be orientated to fall into the vent opening notch in the fill's throat. This prevents rotation when the device is removed.
4. To remove the device, insert key and turn counterclockwise 90 degrees. This will retract the locking cams, not allowing the key to be removed, and thus allowing the removal of the insert from the fill by using the key as a handle pull. On 1318 fills, place a finger on the top of the device, using one of the two ribs on the top to prevent rotation of the device while the key is rotated counterclockwise.
5. To make model 0542 and 0543 fills compatible, the plastic cap retainer system must be removed. To do this:
 - a. Locate the small rectangular loop in the fill neck that retains the end of the plastic retainer strap.
 - b. Using a plastic handled flat screwdriver and small hammer, place the blade of the screw driver on one of the sides of the rectangular loop. Lightly strike the screwdriver to shear one side of the rectangle loop off of the throat of the fill. Strike hammer to the plastic handle of the screwdriver only.



WARNING: Do not strike any metal with a hammer while fuel cap is removed. A spark could result and ignite the fuel vapors causing serious injury or death.

- c. Remove the strap from the open loop, then remove the strap from the cap and discard the strap.
- d. Using a pair of pliers, tear the remainder of the rectangular loop from the throat of the fill and discard.

09/15
0525INS1



Compatible Fuel Fills



PERKO
Fig. 0540 &
0541



PERKO
Fig. 0580
& 0582



PERKO
Fig. 0581
& 0583



PERKO
Fig. 0590
& 0591



PERKO
Fig. 0542
& 0543



PERKO
Fig. 1318



U.S. Marine
PN: 72502
Made by PERKO