



# TABLE OF CONTENTS

## 1 SAFETY

|                                    |      |
|------------------------------------|------|
| INTRODUCTION                       | 1-1  |
| CLEANING, WAXING,<br>AND POLISHING | 1-1  |
| CONTROLLING CORROSION              | 1-2  |
| PROPELLERS                         | 1-3  |
| FUEL SYSTEM                        | 1-8  |
| LOADING                            | 1-10 |
| HORSEPOWER                         | 1-11 |
| FLOTATION                          | 1-11 |
| EMERGENCY EQUIPMENT                | 1-13 |
| COMPASS                            | 1-15 |
| POWER STEERING SYSTEM              | 1-18 |
| ANCHORS                            | 1-18 |
| MISCELLANEOUS EQUIPMENT            | 1-18 |
| BOATING ACCIDENT REPORTS           | 1-19 |
| NAVIGATION                         | 1-19 |

## 2 TUNING

|                                |      |
|--------------------------------|------|
| INTRODUCTION                   | 2-1  |
| TUNING FOR PERFORMANCE         | 2-1  |
| MECHANICAL TASKS               | 2-1  |
| IGNITION                       | 2-5  |
| FUEL SYSTEM                    | 2-9  |
| Carburetor Adjustment          | 2-9  |
| Calibration for High Altitudes | 2-10 |

## 3 ENGINE

|                            |     |
|----------------------------|-----|
| GENERAL PRINCIPLES         | 3-1 |
| Piston Stroke & Combustion | 3-1 |
| Valve Timing               | 3-3 |
| Engines Covered            | 3-3 |
| Chapter Organization       | 3-3 |
| TROUBLESHOOTING            | 3-3 |
| Cranking System            | 3-4 |
| Ignition System            | 3-4 |

|                            |      |
|----------------------------|------|
| Fuel System                | 3-4  |
| Compression                | 3-5  |
| MECHANICAL PROBLEMS        | 3-6  |
| Leak Test                  | 3-6  |
| Dynamometer Testing        | 3-6  |
| Excessive Oil Consumption  | 3-7  |
| Engine Noises              | 3-7  |
| ENGINE REMOVAL             | 3-8  |
| General Information        | 3-8  |
| Removal                    | 3-8  |
| ENGINE INSTALLATION        | 3-12 |
| INTAKE & EXHAUST MANIFOLDS |      |
| SINGLE OHC ENGINES         | 3-16 |
| INTAKE & EXHAUST MANIFOLDS |      |
| DOHC ENGINES               | 3-17 |
| HEAD SERVICE -- SINGLE OHC | 3-23 |
| HEAD SERVICE -- DOHC       | 3-24 |
| HEAD RECONDITIONING        | 3-28 |
| Valve Guides               | 3-30 |
| Valve Springs              | 3-30 |
| Valves                     | 3-31 |
| Valve Mechanism            | 3-32 |
| Hydraulic Lifters          | 3-32 |
| CAMSHAFT SERVICE -- SINGLE |      |
| OHC ENGINE                 | 3-35 |
| CAMSHAFT SERVICE -- DOHC   | 3-39 |
| VALVE LASH ADJUSTMENT      |      |
| SINGLE OHC ENGINE          | 3-43 |
| VALVE LASH ADJUSTMENT      |      |
| DOHC ENGINE                | 3-45 |
| TIMING BELT SERVICE        |      |
| SINGLE OHC ENGINE          | 3-46 |
| TIMING BELT SERVICE        |      |
| DOHC ENGINE                | 3-49 |
| PISTON, RING, AND          |      |
| ROD SERVICE                | 3-51 |
| Removal & Disassembling    | 3-52 |
| Cleaning & Inspecting      | 3-53 |
| Pistons and Pins           | 3-54 |

|                                  |      |                                  |      |
|----------------------------------|------|----------------------------------|------|
| <b>3 ENGINE (Continued)</b>      |      | Primary Circuit Test             | 5-4  |
| Piston Assembling                | 3-56 | Contact Point Test               | 5-4  |
| Cylinder Bores                   | 3-57 | Condenser Test                   | 5-5  |
| Rod Bolts & Nuts                 | 3-58 | Secondary Circuit Test           | 5-6  |
| Rings                            | 3-58 | Rotor Test                       | 5-6  |
| All Blocks, Including DOHC       | 3-60 | Ignition Voltage Tests           | 5-6  |
| CRANKSHAFT & MAIN BEARINGS       | 3-62 | Spark Plug Evaluation            | 5-9  |
| Checking Main Brg. Clearance     | 3-63 | <b>BOSCH DISTRIBUTOR SERVICE</b> | 5-11 |
| Crankshaft Removal               | 3-66 | Removal                          | 5-13 |
| Cleaning                         | 3-67 | Disassembling                    | 5-13 |
| Installation                     | 3-68 | Cleaning & Inspecting            | 5-15 |
| BELL HOUSING SERVICE             | 3-71 | Assembling                       | 5-16 |
| OIL PUMP SERVICE                 | 3-72 | Installation                     | 5-20 |
|                                  |      | Adjusting Dwell                  | 5-20 |
| <b>4 FUEL</b>                    |      | Adjusting Ignition Timing        | 5-20 |
|                                  |      | <b>RENIX ELECTRONIC IGNITION</b> | 5-21 |
| INTRODUCTION                     | 4-1  | Description and Operation        | 5-21 |
| Single Diaphragm Fuel Pump       | 4-1  | Checking Renix System            | 5-22 |
| Cold & Hot Engine Start System   | 4-1  | Troubleshooting                  | 5-23 |
| TROUBLESHOOTING                  | 4-2  |                                  |      |
| Rough Engine Idle                | 4-2  | <b>6 ELECTRICAL</b>              |      |
| Excessive Fuel Consumption       | 4-3  | INTRODUCTION                     | 6-1  |
| Engine Surge                     | 4-3  | BATTERIES                        | 6-1  |
| FUEL LINE & FUEL PUMP TESTS      | 4-3  | Marine Batteries                 | 6-1  |
| Fuel Line Test                   | 4-4  | Battery Construction             | 6-2  |
| Fuel Pump Testing                | 4-4  | Battery Ratings                  | 6-2  |
| Fuel Pump Pressure Test          | 4-4  | Battery Location                 | 6-2  |
| Fuel Pump Volume Test            | 4-5  | Battery Service                  | 6-2  |
| VOLVO FUEL PUMP SERVICE          | 4-5  | Jumper Cables                    | 6-5  |
| FUEL SYSTEM ACCESSORIES          | 4-6  | Storage                          | 6-5  |
| CARBURETORS                      | 4-6  | Dual Battery Installation        | 6-5  |
| Introduction                     | 4-6  | GAUGES AND LIGHTS                | 6-7  |
| "Sour" Fuel                      | 4-7  | Constant Voltage System          | 6-7  |
| Carburetor Service               | 4-7  | Oil & Temperature Gauges         | 6-7  |
| SOLEX DOWNDRAFT                  |      | Warning Lights                   | 6-7  |
| CARBURETOR                       | 4-7  | Thermomelt Sticks                | 6-8  |
| Description and Operation        | 4-7  | Fuel Gauges                      | 6-8  |
| Removal                          | 4-8  | Fuel Gauge Hookup                | 6-9  |
| Disassembling                    | 4-8  | Fuel Gauge Troubleshooting       | 6-9  |
| Cleaning & Inspecting            | 4-12 | Tachometer                       | 6-10 |
| Assembling                       | 4-12 | HORNS                            | 6-11 |
| Critical Plate & Gasket Words    | 4-18 | CHARGING SYSTEM                  | 6-11 |
| Adjustments -- Single Carburetor | 4-19 | Alternator Description           |      |
| Critical Idle & Mixture          |      | and Operation                    | 6-12 |
| Adjustment Words                 | 4-19 | Alternator Protection            |      |
| <b>5 IGNITION</b>                |      | During Service                   | 6-13 |
|                                  |      | Troubleshooting                  | 6-13 |
| DESCRIPTION                      | 5-1  | SERVICE PRESTOLITE               |      |
| Ballast Resistor                 | 5-2  | CHARGING SYSTEM WITH             |      |
| Ignition Timing                  | 5-2  | INTEGRAL REGULATOR               | 6-16 |
| TROUBLESHOOTING                  | 5-3  | Disassembling                    | 6-17 |
| System Tests                     | 5-3  | Cleaning & Testing               | 6-17 |
| General Tests                    | 5-4  |                                  |      |

|                           |      |                                 |             |
|---------------------------|------|---------------------------------|-------------|
| CRANKING SYSTEM           | 6-19 | <b>9 TILT/TRIM</b>              |             |
| Troubleshooting           | 6-19 | INTRODUCTION                    | 9-1         |
| BOSCH CRANKING MOTOR      | 6-22 | Tilt                            | 9-1         |
| Description and Operation | 6-22 | Trim                            | 9-1         |
| Servicing                 | 6-22 | TROUBLESHOOTING                 | 9-2         |
| Disassembling             | 6-24 | Tilt System                     | 9-2         |
| Cleaning & Inspecting     | 6-26 | Tilt/Trim System                | 9-3         |
| Assembling                | 6-27 | TILT SYSTEM SERVICE             | 9-4         |
| Testing Completed Work    | 6-30 | Removal & Disassembling         | 9-4         |
| Installation              | 6-30 | Cleaning & Inspecting           | 9-9         |
|                           |      | Assembling & Installation       | 9-9         |
| <b>7 COOLING</b>          |      | TRIM SYSTEM SERVICE             | 9-13        |
| DESCRIPTION               | 7-1  | Removal & Disassembling         | 9-13        |
| "RAW" WATER STRAINER      | 7-3  | Cleaning & Inspecting           | 9-14        |
| HEAT EXCHANGER            | 7-3  | Assembling & Installation       | 9-15        |
| Disassembling             | 7-5  | TRIM SENDER SERVICE             | 9-16        |
| Assembling                | 7-5  |                                 |             |
| "RAW" WATER PUMP          | 7-6  | <b>10 STEERING</b>              |             |
| THERMOSTAT                | 7-7  | DESCRIPTION                     | 10-1        |
| OIL COOLER                | 7-8  | SYSTEM MAINTENANCE              | 10-3        |
|                           |      | SERVO VALVE ADJUSTMENT          | 10-3        |
| <b>8 STERN DRIVE</b>      |      | POWER STEERING COOLER           | 10-4        |
| INTRODUCTION              | 8-1  | POWER STEERING KIT              | 10-4        |
| OPERATION                 | 8-1  |                                 |             |
| TROUBLESHOOTING           | 8-2  | <b>11 MAINTENANCE</b>           |             |
| SERVICE PRECAUTIONS       | 8-3  | IN-SEASON MAINTENANCE           | 11-1        |
| PROPELLER SERVICE         | 8-3  | OFF-SEASON STORAGE              | 11-5        |
| Removal                   | 8-3  | PRE-SEASON PREPARATION          | 11-8        |
| Change Propeller Rotation | 8-5  | ADJUSTING BOAT TRIM             | 11-10       |
| Retaining Pawl Adjustment | 8-5  | ADJUSTING TRIM TAB              | 11-10       |
| Installation              | 8-6  | FIBERGLASS HULLS                | 11-10       |
| STERN DRIVE REMOVAL       | 8-8  | BELOW WATERLINE SERVICE         | 11-11       |
| STERN DRIVE INSTALLATION  | 8-10 |                                 |             |
| UPPER GEAR ASSEMBLY       | 8-12 | <b>APPENDIX</b>                 |             |
| Disassembling             | 8-13 | METRIC CONVERSION CHART         | A-1         |
| Cleaning & Inspecting     | 8-19 | DRILL SIZE CONVERSION CHART     | A-2         |
| Assembling                | 8-21 | TORQUE VALUES                   | A-3         |
| INTERMEDIATE HOUSING      | 8-36 | TUNE-UP ADJUSTMENTS             | A-4         |
| Disassembling             | 8-36 | ENGINE SPECIFICATIONS           | A-6 to A-17 |
| Cleaning & Inspecting     | 8-41 | CARBURETOR SPECIFICATIONS       | A-18        |
| Assembling                | 8-42 | WIRING DIAGRAMS                 |             |
| LOWER UNIT                | 8-47 | AQ131 & AQ230 (Model 230        |             |
| Preparation               | 8-47 | & 250                           | A-19        |
| Disassembling             | 8-48 | Model 230 & 250 w/control panel |             |
| Cleaning & Inspecting     | 8-52 | layout No. 2                    | A-20        |
| Assembling                | 8-54 | AQ171 (Model 251) DOHC          |             |
| Shim Calculation          | 8-55 | w/control panel layout No. 1    | A-21        |
| Checking "Backlash"       | 8-59 | Model 251 DOHC w/control        |             |
| EXTENSIONS                | 8-62 | panel layout No. 2              | A-22        |
| TRANSOM SHIELD            | 8-62 |                                 |             |