SUP/KAYAK RACK ASSEMBLY INSTRUCTIONS

Tools Required:

- Drill Bit 3/8" (wood) or 1/2" (concrete)
- 5/16" wrenches or sockets

PART LISTING

PART	QTY.	DESCRIPTION
Α	2	Base
В	2	Post
С	4	Arms
D	4	Straps
Ε	6	5/16" x 2-1/4" Hex Head Bolt
F	6	5/16" Nuts and Washers

Dock Assembly:

- Place Base (A) in desired location on dock and mark hole locations onto dock surface. Drill through surface using appropriate drill bit for your dock. Fasten Base with 1/2" Lag Bolts or through bolts (not supplied) using predrilled holes.
- Insert Post (B) as shown into Base and fasten using supplied Hex Head Bolt (E), Washer and Nut (F).
- 3. Attach Arm (C) using supplied Hex Head Bolt (E), Washers and Nuts (F) as shown.
- 4. Insert Straps (D) through holes on Arms (C).

Wall/Vertical Assembly:

- Place Post (B) in desired location on wall and mark hole locations (X) onto wall surface. Drill through surface using appropriate drill bit.
- 2. Remove Post and attach Arms (C) using supplied Hex Head Bolts (E), Washers and Nuts (F) as shown.
- Reposition assembled rack on wall and fasten with appropriate fasteners (not supplied) using predrilled holes.
- 4. Insert Straps (D) through holes on Arms (C).

