## **DPPRY6** Cutout Template

## Installation Instructions:

6 7/16"

 Carefully cut along dotted line
Tape down template on location to be mounted
Carefully cut hole where hatch is to be mounted
Place hatch in hole mark/drill fastener holes
Apply generous bead of marine grade silicone to mounting surface and place frame into place
Install fasteners and be careful not to over tighten