

THE ORIGINAL  
**FATSAC**  
 BALLAST BAG CO.



PART#	DESCRIPTION	• Fittings made for automatic ballast systems
W730	Female Quick Connect with Chain & Cap — Sac Valve Threads	
W739	Quick Connect Cap	
W731	Wally Plug — Sac Valve Threads	
W732	Female GHT — Male Quick Connect	
W733 •	1" Barbed End — Sac Valve Threads — Should be screwed into Pro X Sac with all-purpose PVC cement	
W734	Male Quick Connect — Tsunami Pump Thread	
W735	Female Quick Connect — Blue perfect union bed valve fitting	
W736 •	3/4" Quick Connect — Sac Valve Threads -- Should be screwed into Pro X Sac with all-purpose PVC cement	
W737 •	3/4" Barbed End — Sac Valve Threads — Should be screwed into Pro X Sac with all-purpose PVC cement	
W738	Male Quick Connect — 1 1/8" Barbed Tsunami Pump Hose End	
W740 •	Flow-Rite 3/4" Straight Quick Connect Socket	
W741 •	Flow-Rite 1-1/8" Straight Quick Connect Socket	
W742 •	Flow-Rite 3/4" Elbow Quick Connect Socket	
W746 •	Flow-Rite 1-1/8" Elbow Quick Connect Socket	
W743 •	1-1/8" Quick Connect — Sac Valve Threads — Should be screwed into Pro X Sac with all-purpose PVC cement	
W743-DOUBLE •	Double Sided 1-1/8" Quick Connect Fitting	
W743-SS •	Suction Stop Sac Valve Threads — 1-1/8" Quick Connect — Should be screwed into Pro X Sac with all-purpose PVC cement	
W744	Pro X Series Check Valve — All Check Valves slow the flow — It takes 5 minutes longer to fill using them	
W745	3/4" Barbed Tsunami Pump Fitting	
W747	Sac Valve Thread For Tsunami Pump — Should be screwed into Pro X Sac with all-purpose PVC cement	
W748 •	1-1/8" Quick Connect To 1" Barbed	
W749	Air Release Plug — Turn To Release Air — For manual filling, not for venting automatic systems	
W753 •	1" Barbed In-Line Check Valve	
W755 •	1-1/8" Barbed In-Line Check Valve	

**NOTE:** There are many possible combinations using our Quick Connect fittings. If you are trying to accomplish something and aren't sure how to best handle it, please contact us and we will be glad to help.

**IMPORTANT:** Use All-Purpose PVC Cement on the threads of the W733, W736, W737, W743, and W747 when screwing them into Fat Sacs.

# NEW! SUPA TSUNAMI PUMP UPDATE (W709-SUPA)



## INSTRUCTIONS FOR THE NEW FAT SAC JUICED EDITION SUPA TSUNAMI QUICK CONNECT PUMP SYSTEM

- [1] Most lightweight, user friendly, and fastest system from start to finish
- [2] Quick connect valve for fill & empty
- [3] 12 volt plug & play
- [4] New clear reinforced, kink-proof, black helical, tiger hose

The new juiced Supa Tsunami Pump is the fastest, most compact and lightweight pump that you put over the side of the boat and plug into the cigarette lighter accessory plug to manually fill and empty the Fat Sacs. It is made to go on and off the Fat Sacs very fast and easy to save time. The new tiger hose on the Supa Tsunami Pump (W709-SUPA) allows you to clearly see when the water is flowing good. It also allows you to see if there are any air bubbles, weeds, sand or dirt in it that are slowing the flow or are being pumped into your Fat Sac.

**NOTE: USE MORE THAN ONE SUPA TSUNAMI PUMP TO SAVE TIME FILLING AND EMPTYING ONE OR MULTIPLE SACS.**

### QUICK TIPS FOR USING THE SUPA TSUNAMI PUMP (W709-SUPA)

**STEP 1:** First put the Supa Tsunami Pump over the side of the boat under the water.

**STEP 2:** Then counter twist the end of the hose before sticking it in the quick connect with cap and chain on the top of the Fat Sac so it twists back and holds itself in the groove.

**STEP 3:** Plug the Supa Tsunami Pump into the cigarette lighter accessory plug.

**NOTE:** To empty do the same thing except the end of the hose goes over the side of the boat first and pump goes on the quick connect with cap and chain on top of the Fat Sac. Then push the pump down into the Sac to prime the Pump.

**WARNING:**

- Do not fill Sacs unattended.
- Do not exceed weight limits for boat capabilities.
- No sharp turns when using Sacs.
- No fast starts and stops with using Sacs.
- Do not be under the influence of drugs and/or alcohol when using Fat Sacs period.

