



Adapter Retrofit Kit

1. Make sure mounting feet are rotated inward to allow proper fit through the mounting hole
2. Insert Retrofit Bracket into mounting hole up to 2.75" in diameter
3. Tighten 3 - #6 mounting screws until adapter is firm against the mounting surface
4. After wiring, insert Down Light into the Retrofit Bracket and rotate clockwise to secure it in place

