



# CHARGER INLETS

## INSTALLATION INSTRUCTIONS

(PART #'S: 150BBI, 150BBIW, 200BBIW, 150BBI.OEM, 150BBIW.OEM, 200BBIW.OEM)



**WARNING: Failure to comply with the following instructions could cause an electrical failure or fire.**

### Instructions:

- 1) Drill a 1-7/8" diameter hole.
- 2) Cut the plug off of the battery charger cord.
- 3) Feed the cord through the rear boot and mounting ring (if used).
- 4) Strip the battery charger cord jacket 1-1/8" and each individual wire 9/16"
- 5) Insert the green (or green with yellow stripe) wire into the terminal with the green screw. (DO NOT OVER TIGHTEN!)
- 6) Insert the white (or blue) wire into the terminal with the silver screw.
- 7) Insert the black (or brown) wire into the terminal with the black screw.
- 8) Slide the rear boot over the back end of the charger inlet.
- 9) Place the charger inlet in the hole with the "U" shaped plug blade in the 12 o'clock position.
- 10) Secure the inlet from the front using the 3 #6 screws (included) or from the back using the threaded mounting ring.