



FOLLOW DETAILED INSTRUCTIONS BELOW

● INSTALLATION INSTRUCTIONS

1. Viewing the stern drive from the outside of the boat, locate the six (6) nuts now holding the stern drive unit to the bellhousing.
2. Remove one nut as shown in Figure A from the stern drive unit, leave flat washer in place.
3. Insert the key into the lock. Turn the key until it drops into place and engages the lock. Thread the lock and key assembly on the stud by hand until finger tight, using a torque wrench final tighten the assembly to the torque specifications below. Remove key and store in a safe place.
4. Install vinyl cap over the lock by pushing the cap on until it touches the stern drive housing.

TORQUE SPECIFICATIONS

- A. 50 ft. lbs. MerCruiser Alpha & Bravo, OMC Cobra & King Cobra, Yamaha, Volvo SX & DP Stern Drive.
- B. 75 ft. lbs. MerCruiser TRS & SSMII.
- C. 100 ft. lbs. MerCruiser SSMIII, SSMIV, SSMV, SSMVI.

Helpful Hints: Keep your key and I.D. Card in a safe place. The key will be needed when you bring your sterndrive in for service. You will need the I.D. card if you wish to order an extra key.

Figure A

