

TOOLS REQUIRED

- Phillips head screwdriver
- 1/16" drill bit
- Hole punch (3/16" minimum)
- Cigarette lighter

INSTRUCTIONS

1. Where deck carpet and fiberglass side meet, drill two 1/16" holes using a template. Screw Trolling Motor Tie Down into deck using screws and screw plate.
2. Loosen belt through adjustable slide.
3. Match hook and loop fastener evenly and adjust slide so that patch is positioned on top of the motor shaft. Tighten belt so that trolling motor is secured.
4. Tuck strap into the slide and trim off excess belt leaving 2-3" for the application of the push pegs. (The push pegs are necessary to keep the belt from sliding through the adjustable slide in rough water conditions.) Using a cigarette lighter, melt and seal the raw edge of the slide belt. Make sure you have your belt properly adjusted on the trolling motor, prior to inserting the pegs as they are not removable. To install the push pegs, push male pegs through the belt approximately one inch apart. Once the holes are punched, push the pegs through and be sure they are snapped closed. Using the lighter, melt down the portion of the male peg that protrudes past the female peg to form a permanent seal.



1.



2.



3.



4.