

WARNING! Do Not Use ACETONE To Clean The Polycarbonate Lens. Use Alcohol and Soft Cloth.

10.00" [254mm]

Top View

2.375" [60mm]

Height

.5" [13mm]

8.70" [221mm]

Top

Side View

.35" [9mm]

1" (#8)
Stainless screw

Bottom Base Plate

18 Gauge
Tinned Wire

.5" [12.5mm]

1" [25mm]
316 Stainless
Phillips Head
Self-Tapping
Screws

PLEASE READ INSTRUCTIONS INSIDE TEMPLATE

TAPE
HERE

TAPE
HERE

FOR CENTER WIRE HOLE USE THE FOLLOWING:

DO NOT USE TEMPLATE
TO MARK SCREW HOLES

DO NOT USE TEMPLATE
TO MARK SCREW HOLES

1st - DRILL PILOT HOLE AT CENTER FOR THE WIRE, THEN USE 5/8" DRILL ALL THE
WAY THROUGH

**WHEN PRE-DRILLING SCREWS:
FIRST PRE-DRILL
CENTER HOLE AND RUN
WIRE. THEN MARK YOUR
SCREW HOLES WITH DRILL BIT
OR PENCIL WHILE USING
ACTUAL LIGHT HOUSING**

**WHEN PRE-DRILLING SCREWS:
FIRST PRE-DRILL
CENTER HOLE AND RUN
WIRE. THEN MARK YOUR
SCREW HOLES WITH DRILL BIT
OR PENCIL WHILE USING
ACTUAL LIGHT HOUSING**

SCM-CC™/SCM-10™
Typical Power Requirements
3.5 Amps@12v

2nd - RUN WIRE THROUGH THE HOLE AND MARK ONE MOUNTING HOLE LOCATION
3rd - FOLLOW STEPS ON FRONT OF SHEET FOR DRILLING MOUNTING HOLES

Scale 1:1 (if in doubt ask)

TAPE
HERE

TAPE
HERE

Rely on premium marine lighting by Shadow Caster if you're looking for quality and efficiency.

SCM-CC/SCM-10 Installation Diagram