

FLOOR MOUNTED

FOOT TRIM

Install in floor of boat under console in a position which is best suited for the operator.

Wiring Instructions:

- Connect PURPLE wire from HOT TRIM to power or common wire in trim cable.
- Connect BLUE wire from HOT TRIM to up or out wire in trim cable.
- Connect GREEN wire from HOT TRIM to down or in wire in trim cable.

