

Installation Instructions

1. On top of your gunnel, use the measuring tape to find the center point for where you would like to install the Quick Release Fender Lock.
2. Mark the center point with a pen or pencil.
Note: Ensure there are no wires or other obstructions underneath the gunnel before drilling.
3. Using the cordless drill and 1/8" drill bit, carefully drill straight through the gunnel top at the marked center point.
4. Using the cordless drill and the 3/4" hole saw, carefully enlarge the pilot-hole created by the drill bit.
Note: When drilling both holes, ensure the bit and hole saw are perpendicular to the top of the gunnel. This will eliminate the Fender Lock being installed at an angle.
5. Remove the Quick Release Fender Lock Receiver from the Locking Pin.
6. Clean the surface around the hole just drilled with isopropyl alcohol.
7. Under the Receiver top, place a bead of marine-grade sealant.
8. Carefully place the Receiver into the hole that was drilled into the gunnel.
9. Apply gentle pressure to the Receiver top to secure it in place.
10. Under the gunnel, install the flat washer, followed by the nut and tighten them all the way to the underside of the gunnel.
11. Hold the flat edges of the bottom of the Receiver with the 9/16" open-end wrench.
12. While holding the receiver still with the wrench, use the adjustable wrench to tighten the nut to the under-gunnel surface.
13. Using the rag and small amount of WD-40, remove any excess sealant that may spread from under the Receiver top.
14. Allow the marine-grade sealant to dry according to the manufacturer's recommendation.
15. Install the Quick Release Fender Lock locking pin and attach fenders accordingly.

Required* *not included

- MEASURING TAPE
- PEN OR PENCIL
- SAFETY GLASSES
- CORDLESS DRILL
- 1/8" DRILL BIT
- 3/4" HOLE SAW
- ADJUSTABLE WRENCH FOR 1-1/8" SS NUT
- 9/16" OPEN END WRENCH
- MARINE-GRADE SEALANT
- COTTON RAG
- ACETONE / ISOPROPYL ALCOHOL
- WD-40

