

# Installation instructions

## THRU HULL R7

### INSTALLATION

- 1 Make two 15mm [0.59"] holes on the bulkhead (1) (fig.1).
- 2 Assembly the parts as shown in figure (2) and lock the nuts (2) with a 15Nm [11 lb.ft] torque, by means of a 22mm or a 7/8" Allen head wrench.
- 3 Connect the hoses to the extremities and tighten the connection nuts (3) with a 20Nm [15 lb.ft.] torque (fig. 3).

