

WATERLINE DESIGN

1. Open the portlight.
2. Mount the suction cup or magnet according to instruction on the mosquito net.
3. Press the suction or the magnet (magnet and metal plate) to the window. Make sure the suction cup and window is clean for best result.
4. The net will be on the outside of the portlight.
5. Tighten up the blind against the wall / portlight.
6. Use the security line and attach it to the knob on the portlight.

To remove the net, don't pull in the net. First remove the suction cup or magnet with a finger.

[Learn more about boat hatches & ventilation we have.](#)