

Common Application Diagram



LEGEND



ATTENTION:

This document is a general reference diagram for illustrative purposes only and is not an installation diagram or a diagram specific to any particular vessel or vessel model. Installation requirements for individual vessels may vary. Versions of this diagram are subject to change without notice. Blue Sea Systems recommends consulting a certified electrician in connection with the installation of any electrical product. Marine electrical installations should conform to all applicable ABYC standards.

NOTE:

Fuses and breakers may have been omitted for clarity. ABYC overcurrent protection standards and overcurrent recommendations shown in the product instructions should be reviewed and applied to electrical installations.