


FENDER TENDER II®



ENGLISH

Clip for Attaching Boat Fenders

Fender Tender II® simplifies the handling and relocation of boat fenders. Use to clip your fenders to rails, lifelines, side wing windows or cleats. Uses 1/4 to 3/8" (6 mm to 9 mm) diameter nylon line. Made of tough, sun resistant plastic for many years of use. Helps tidy up your boat. Don't dock without it!

To raise fender: Lift fender with left hand. Hold Fender Tender in place with finger tip. Pull up line with right hand as shown and recleat.

