



INSTRUCTIONS

Fish Seeker® is the only fully adjustable "diver" available. Planes at any depth set from 5–80 feet with little pull on the line. Fish Seeker flips over when a fish strikes and goes for the surface. Can be used with side planers.

How to Use

1. Using the chart below, attach your rod end to a lettered hole and your lure or bait (with 4–8 foot leader) to one of the numbered holes. Example; C-4 will take your bait or lure to 40 feet.

2. Let out specified amount of line (100 feet for C-4) and troll at 2 MPH. Fish Seeker will dive and level off at the desired depth even if more line is let out.

3. When a fish strikes, Fish Seeker will turn over and go for the surface. In the event of a false strike, simply slack the line and Fish Seeker will dive again and level out at your preset depth.

4. Fish for WALLEYE, STRIPER, CRAPPIE, STEEL-HEAD, TROUT and SALMON with full depth control and minimum line drag.

TROLL at 2 MPH (3.2 km/hr)
Use with light tackle
6-25# test

Always use ball bearing swivels.
Not for use with deep-diving lures.

Desired Depth	Hole Setting	Amount of Line	Desired Depth	Hole Setting	Amount of Line
5 ft. (1.5 m)	A-1	80 ft. (24 m)	45 ft. (13.5 m)	D-3	100 ft. (30 m)
10 ft. (3.0 m)	A-2	80 ft. (24 m)	50 ft. (15.5 m)	D-4	100 ft. (30 m)
15 ft. (4.5 m)	B-2	80 ft. (24 m)	55 ft. (17.0 m)	D-5	100 ft. (30 m)
20 ft. (6.0 m)	B-3	80 ft. (24 m)	60 ft. (18.5 m)	E-3	100 ft. (30 m)
25 ft. (7.5 m)	B-4	80 ft. (24 m)	65 ft. (20.0 m)	E-4	100 ft. (30 m)
30 ft. (9.0 m)	C-2	80 ft. (24 m)	70 ft. (21.5 m)	E-5	120 ft. (37 m)
35 ft. (10.5 m)	C-3	80 ft. (24 m)	75 ft. (23.0 m)	F-4	120 ft. (37 m)
40 ft. (12.0 m)	C-4	100 ft. (30 m)	80 ft. (24.5 m)	F-5	120 ft. (37 m)

WARNING: This product contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm.