

NavNet 3D MFDBB – Single, Clone & Extended Mode Description

SINGLE

One monitor, one MCU001 keyboard and one MFDBB processor.



DUAL (CLONE MODE)

Two monitors, two MCU001 keyboards and one MFDBB processor. This mode is used when there are two stations at different locations on the boat. Both stations will display identical displays at all times.



DUAL (EXTENDED MODE)

Two monitors, one MCU001 keyboard and one MFDBB processor. This mode is used when two monitors are needed at the same station, but with different displays and information on each. The cursor can be moved back and forth between the monitors to individually control the features of each.

