Instructions for:

12.172

Model 75025 & 75225 Adjustable Table Pedestal

## PEDESTAL MOUNTING INSTRUCTIONS

- 1. Locate a place for mounting pedestal. Ensure there is an open 6" space below deck and no cables or reinforcement ribs are in mounting area.
- Set pedestal on deck where it will be mounted. Unscrew locking knob to allow pedestal to slide. While holding down on the inside tube assembly, slide the outside tube up in order to trace around the inside tube. While still holding the inside tube assembly, slide outside tube assembly back down to the deck and mark the 6 mounting holes for the base.
- 3. Cut out center circle in deck. This hole is for the inner tube when the pedestal is in the lower position.
- 4. Drill the six mounting holes in deck using the proper bit that is compatible with the selected fasteners. **NOTE: Fasteners not provided.**
- 5. Place pedestal on deck and align the holes in base with holes in deck. Check pedestal for proper up and down travel.
- Secure pedestal to boat deck. This deck area should be adequately reinforced. Use a backing plate if necessary to make a secure attachment. It is recommended that the fasteners go through both deck and backing plate for best results (See Fig. 1).

## TABLE ATTACHMENT INSTRUCTIONS

- 1. Loosen, don't remove, locking knob in order to slide inside tube out of the assembly.
- 2. Mount table to top base using appropriate fasteners.
- Slide inside tube assembly back into outside tube. The lock block attached to the knob (A) will need to align with the track on inside tube.
- 4. Once correctly inserted, secure pedestal in position at desired height by tightening knob.



