

Instructions for:

Side Mount Table Hardware

12.601

Installation Instructions:

- 1. Locate mounting bracket in desired location (note: bracket is made with a 3 degree slant to accommodate most boat surfaces. If the surface that the bracket is being mounted due is greater or less than 3 degree the bracket will need to be shimmed in order to make a level table).
- 2. Ensure bracket is level, at the desired height, and mount to the boat surface using ½" marine grade pan headed fasteners (Note: fasteners are not provided due to the large variety of mounting surfaces and thicknesses).

Caution: Insure area behind bracket is free of from obstacles such as fuel tanks, hoses, electrical wires, etc.

It is recommended that a backer plate or a suitable substrate be used to handle table loading. See boat manufacturer recommendations for location or specific needs.

Operation Instructions:

- 1. To insert table assembly pull back on mounting bracket locking knob and insert side mount table leg until it is wedges securely in place.
- 2. To remove table assembly pull back on mounting bracket locking knob and pull up on table leg.

Maintenance:

- 1. Periodically check and tighten all mounting hardware attachment points.
- 2. Ensure cleanliness of equipment to prevent dirt, rocks, or debris from damaging sliding surfaces.

