



## TWIST-LOCK TESTER

**Installation Instructions catalog no.'s**  
HBLT2311, HBLT2611, HBLT2331, HBLT3721, HBLT26CM11

**CAUTION:** This device introduces low level current into the grounding path. Use with caution in patient care areas.

**NOTICE:** The safe operation of most cord connected equipment is dependent upon correct wiring of the outlet to which it is connected. If faulty wiring is indicated, consult a qualified electrician for correction. Do not use outlet until correction is made.

### NOTICE:

- All appliances or equipment on the circuit being tested should be unplugged to help avoid erroneous readings. Stray currents passing through such equipment to ground can introduce false tester indications.
- Not a comprehensive diagnostic instrument but a simple instrument to detect nearly all probable common improper wiring conditions.
- Refer all indicated problems to a qualified electrician.
- Will not indicate quality of ground.
- Will not detect a combination of defects.
- Will not indicate reversal of grounded and grounding conductors.

### TESTER INDICATES:

| CONDITIONS        | ○ | △ | ⊕ |
|-------------------|---|---|---|
| Correct           | ○ |   | ⊕ |
| Reverse Polarity  | ○ | △ |   |
| Open Ground       | ○ |   |   |
| Open Neutral      |   |   | ⊕ |
| Open Hot          |   |   |   |
| Hot & Ground Rev. |   | △ | ⊕ |
| Hot on N, No Hot  | ○ | △ | ⊕ |