

How to apply



Do not use below 10°C / 50°F
Suitable for above the waterline use.

Prepare

1. Grab a cup of soapy water, flush out the chip, then rinse it out with clean water.
2. Allow to fully dry in sun or accelerate dry with a hairdryer.
3. Give the tube a massage / knead for about two minutes to prepare and mix.

Apply

4. Squeeze enough 9 Second Chip Fix to slightly overfill the damage (whilst holding a tissue in your spare hand).

Level

5. Quickly turn tube up the opposite way to use the level scraper on the end of tube.
6. Start from the centre of the chip, very gently level scrape toward the outer edge at 90°. Repeat from the centre to the opposite side. Don't worry if the repair's not perfect at this stage, it will be fixed with the next layer.

Trim

7. Now clean the level scraper with a tissue and use it again to trim and scrape away any excess smears. Avoid excessive tampering.
8. For a fully filled repair, it will need at least 2 coats of 9 Second Chip Fix. Wait 2 hours in between coats.
9. **IMPORTANT** – If the temperature is expected to drop below 20°C / 70°F within 24 hours, blow dry the repair with a warm hairdryer for about 2 minutes after each coat.

Allow 48 hours before subjecting the repair to moisture or contact. MagicEzy will continue to strengthen and harden over the next 21 days.