

# Marine Kettle Gas Grill

## Trouble Shooting Guide

<b>Problem</b>	<b>Possible Cause</b>	<b>Possible Solution</b>
<b>Burner will not light</b>	No gas flow	Check fuel level, refill cylinder or replace canister
	Obstruction of gas flow	Visually check for obstructions / debris & clean inside of venturi tube & burner with a clean cloth
	Disconnected gas supply	Make sure canister is properly attached
<b>Flare up</b>	Grease and/or residue build-up	Clean internal components
	Excessive fat in meats	Trim fat from cuts of meat before grilling
	Excessive oils in marinades	Use non-oil based marinades
	Excessive cooking temperature	Reduce valve setting, leave lid open, or spray with water to cool
<b>Yellow sooty flame</b>	Obstruction of gas flow	Visually check for obstructions / debris & clean inside of venturi tube & burner with a clean cloth
<b>Flame goes out</b>	Valve/flame setting too low	Increase valve setting & relight
	Valve set to low, lid is closed or opened to quickly	Increase valve setting & relight
	Empty fuel supply	Refill fuel tank or replace canister
	High or gusty winds	Rotate valve / venturi tube assembly to downwind side of grill. Increase temperature setting & relight
	Wind directly on grill surface	<u>Non-hinged lid grills:</u> Use grill lid as windshield to block wind by attaching to windward side of grill (see page 5 of owners manual) <u>Hinged lid grills:</u> Rotate grill to use lid as windshield on windward side (see page 4 of owners manual)
	Obstruction of gas flow	Visually check for obstructions / debris & clean inside of venturi tube & burner with a clean cloth

