Installation, Care & Use Instructions

R10-1010-30 • R10-1010-36 • R10-1020

Stainless Steel Storage Arms with Foam Pads + Protective Covers for Magma Kayak/SUP Storage Racks

INSTALLING STORAGE ARMS TO RACK

Once necessary space required between equipment is determined, vertically space arms accordingly. Fit attachment bracket over vertical upright and install (2) 1/4"-20 x 2" button socket cap screws with (2) 1/4"-20 nylock nuts and secure using a 7/16" wrench with 5/32" hex key wrench.

NOTE: To maximize storage potential, start installing arms from the racks top set of holes and working down allowing minimum space necessary between each water toy.





CONTENTS

- (2) Stainless steel storage rack arms with foam pads + 600D polyester protective covers
- $(4) 1/4"-20 \times 2"$ Stainless steel button socket
 - cap screws
- (4) 1/4"-20 Stainless steel nylock nuts
- (1) 5-/32" Hex key wrench

7/16" Wrench

ADJUSTING RACK ARMS TO FIT EQUIPMENT

If additional adjustment is required to fit larger or smaller equipment simply remove attachment fasteners, reposition arms in the desired location and repeat the installation procedure.



EXAMPLES OF ARM STYLES AND CONFIGURATIONS (SHOWN) OR MIX AND MATCH TO ADAPT THE SYSTEM TO YOUR SPECIFIC REQUIREMENTS

 (Securing Tie-Down Straps Not Included) Attach hook of tie-down strap to rack's arm connection bracket at the main frame, extend over equipment, and connect strap to tie-down point 	 CARE & USE Kayak's and SUP's should be secured to rack when not in use Periodically wash rack with environmentally friendly boat soap, fresh water, and a clean cloth to remove any debris, wipe dry Water toys should always be rinsed with fresh water before storing
---	--

