

**⚠ CAUTION!** Before working on trolling motor, be sure that the battery cables are not connected to the battery.

## Instructions:

1. Insert handle into the opening of the trolling motor head as shown in Figure 1. Press firmly until there is no gap between the trolling motor head and the black portion of the handle.
2. Rotate handle in both directions to ensure that the maximum speed indicator for forward and reverse align with the rotational stop.
3. Extend the handle and pull firmly to ensure that it is properly locked in place.

**Note:** Handle installation is permanent. Do not attempt to remove the handle.

*Figure 1*

