




# Digital Line Counter Operating Instructions

# RAPALA®



When mounting on a baitcasting rod position on topside in front of the reel (fig A). Clamp and tension strap. Open line guide arm and run line over top of spool, pushing line down into mechanism.



When mounting on spinning rod position on underside close to first line guide (fig B). Clamp and tension strap. Open line guide arm and run line under the bottom of reel, pulling line up into mechanism.

For either rod style, close line guide arm making sure line is nested in corners of the line guide arm. Push towards spool until line guide arm lock's into position.

## Side 2/Inside

**Power On/Off:** Hold power button down for 3 seconds. Screen will flash 3 times then the counter is ready for use.

**Change Unit of Measure:** While powering up and the display is flashing, push the power button again to cycle between (M) Meters or (FT) Feet. When your choice is shown, wait for 3 seconds or until display stops flashing.

**Depth Lock:** Press "Lock Button" to lock depth.

**Depth Lock to Zero:** Press the "Power" button to set Line In/Out back to "0.0." Press the "Depth Lock" button to lock in "0" depth.

**Depth Alarm:** Press the "Depth Alarm" button to turn alarm On/Off. The bell alarm icon will appear in the top left when on.

**Manual Depth Alarm:** Press and hold the "Depth Alarm" button for 3 seconds. While screen is flashing press the "Depth Alarm" button to increase or "Depth Lock" button to decrease number. Distance will appear in upper left corner of screen. Press the "Power" button to select.

**Sleep Mode:** Back light on display will automatically turn off after 10 minutes. Press any button to reactivate.

**Auto Shutoff:** The Digital Line Counter will automatically shut down after 30 minutes of no activity.

