

Mounting template printing instructions

**Caution: Ensure mounting
template is printed
true-to-scale**


Before modifying mounting surface, ensure actual printed template matches the measurements provided in the template document.

**Configuring Adobe Acrobat to use
Raymarine recommended print settings**

Adobe Acrobat must be configured correctly to ensure mounting templates print true-to-scale.

With the mounting template document open in Acrobat Reader:

1. Select **File**→**Properties**.
2. Make a note of the Page Size.
3. Select **File**→**Print**.
The print dialog is displayed.
4. Select **Properties**.
5. Ensure the paper size is set to the same dimensions as the page size identified in Step 1.
6. Click OK to return to the print settings dialog.
7. Ensure "Size Options" and "Page Scaling" options (as appropriate) are set to "Actual Size" or "None".
8. Ensure the "Auto-Rotate and Center" or "Auto portrait / landscape" option (as appropriate) is NOT ticked.
9. Select the relevant orientation to match the template document orientation ("portrait" or "landscape"; most templates are landscape).



IMPORTANT: This document may not print true to scale. Before modifying mounting surface ensure printed template matches the measurements provided.