

Scanstrut Installation Instructions

LMM 1/2










60650 - 4.8x12 Rivet TLP/D 650 x2

72517 - Lacing Eye












Cable Tie x4

S/S Safety Lanyard x1







IMPORTANT

LMM -1 /2 are intended to mount a single radome as stated in the latest Scanstrut Product Guide – subject to change without prior notice.

Use of the LMM-1/2 with unapproved products, or overloading, invalidates any warranty.

No liability is accepted for damage caused by incorrect installation.

This product has been designed specifically for the mounting of approved radar (listed in the Scanstrut Product Guide.) and used under normal boating conditions.

This product is not designed to withstand overload, impact, excessive force or entanglement in sails and rigging.

This product is designed to become detached from the mast in the event of an overload or other abuse, for example, impact, excessive force and entanglement in sails or rigging.

 $The \ safety \ languard \ must be \ fitted \ according \ to \ the \ instructions. \ Failure \ to \ do \ so \ invalidates \ any \ warranty.$

The installation and assembly must be regularly inspected for evidence of damage or loose parts.

This product is designed to suit aluminium masts with a minimum width of 65mm (2.6") and wall thickness in the range 2mm (5/64") - 5mm (3/16").

For installation on non-aluminium masts, or mast sections outside the above sizes, please consult Scanstrut head office.

The assembly is not designed to be fully removed and re-installed once fitted. If bracket needs to be removed for servicing, the unit should be disassembled from the mounting feet by removing the bolts. The feet must remain attached to the mast, and the unit must be re-fitted to the original feet, in their original location.