


# Sea-Dog Light Tip Toggle Switches #420121 - 420129 Wiring Instructions




#### 420121(-1)

On / Off Single Pole / Single Throw Clear Off / Red On

## 420122(-1)

Mom. On / Off Single Pole / Single Throw Clear Off / Red On



#### 420123(-1)


On / Off / On Single Pole / Double Throw Clear Off / Red On

#### 420124(-1)

Mom. On / Off / Mom. On Single Pole / Double Throw Clear Off / Red On

## 420125(-1)

Mom. On / Off / On Single Pole / Double Throw Clear Off / Red On



# 420128(-1)

On / Off / On Double Pole / Double Throw Clear Off / Red On

#### 420129(-1)

Mom. On / Off / Mom. On Double Pole / Double Throw Clear Off / Red On