



Sea-Dog Light Tip Toggle Switches #420121 - 420129 Wiring Instructions




420121(-1)
 On / Off
 Single Pole / Single Throw
 Clear Off / Red On

420122(-1)
 Mom. On / Off
 Single Pole / Single Throw
 Clear Off / Red On



420123(-1)
 On / Off / On
 Single Pole / Double Throw
 Clear Off / Red On

420124(-1)
 Mom. On / Off / Mom. On
 Single Pole / Double Throw
 Clear Off / Red On



420125(-1)
 Mom. On / Off / On
 Single Pole / Double Throw
 Clear Off / Red On

420128(-1)
 On / Off / On
 Double Pole / Double Throw
 Clear Off / Red On

420129(-1)
 Mom. On / Off / Mom. On
 Double Pole / Double Throw
 Clear Off / Red On