PUMP DIAGRAM


FLOAT SWITCH DIAGRAM



1 YEAR LIMITED WARRANTY

All SEACHOICE Pumps and Float Switch

SEACHOICE warrants each new bilge pump and float switch against defects in material and workmanship for a neriod of one year from date of purchase and agrees to repair or replace (at SEACHOICE Option) defective parts without charge. NOTE: Warranty does not cover damage resulting from improper installation, accident, misuse or abuse, or lack of reasonable care. No responsibility is assumed for any special, incidental, or consequential damage. For warranty service, bring the entire unit to the store where it was bought ALONG WITH THE **ORIGINAL BILL OF SALE SHOWING** DATE OF PURCHASE.



(Note: It is important that wire connections be made in a dry location.)

G.P.H.	System	Amps at 3' Head	Fuse Size	Hose Size	Recommended Wire Size
600	12V	3.5 amp	5 amp	3/4" (1.9cm)	16
1000	12V	5.5 amp	7 amp	3/4" (1.9cm)	16
1500	12V	8 amp	10 amp .	1-1/8" (2.85cm)	16
2000	12V	12 amp	15 amp	1-1/8" (2.85cm)	16