

INSTALLATION • Model 20941

CAUTION: Gasoline and its vapors are extremely explosive. Observe installation safety precautions. Do not smoke. Install in well ventilated area away from flame & sparks.

For Gasoline Engines Only.

Not to be used in fuel injected engines.

For ease of installation filter may be installed at the most accessible location between gasoline tank and carburetor.

INSTALLATION IN FLEXIBLE FUEL LINES

- 1. Cut a 3" section of fuel hose in area selected between gasoline tank and carburetor.
- 2. Place one clamp on each end of cut fuel hose.
- **3.** Select hose barbs that fit the I.D. of your fuel line. Screw one into each end of filter housing. Do not over tighten.
- **4.** Lubricate barbs, Push and twist cut end of hose over barbs until seated against hex area of barb.
- **CAUTION:** "OUT" END OF FILTER MUST BE POINTING TOWARDS CARBURETOR. "IN" END TOWARD FUEL TANK OR PUMP.
- 5. Slide clamps over hose barbs and tighten.
- 6. Start engine. CHECK FOR LEAKS.
- **7.** Should a leak occur, immediately stop engine and check your installation.