

# SOLIX® SERIES CONTROL HEAD INSTALLATION GUIDE

532520-3\_B

## Overview

Follow the instructions in this installation guide to gimbal mount the control head. We encourage you to read this guide before starting the installation, so you may understand the installation requirements.

**SUPPLIES:** In addition to the hardware supplied with your control head, you will need a powered hand drill and various drill bits, flat head screwdriver, pencil, safety glasses and dust mask, marine-grade silicone sealant, dielectric grease (optional), extension cables (optional), Ethernet cables (optional), and accessory cables (optional). Also, see **Connect Power** to determine the type of connection, fuse, and additional equipment you will need for the installation.

**Accessories and Ethernet:** Accessories and Ethernet equipment are available for purchase at [humminbird.com](#). The installation guides are available with the product, or they can be downloaded from our Web site.


**NOTE:** For RAM mounting installation, see the FAQ (Frequently Asked Questions) section of our Web site at [humminbird.com](#).

## 1. Plan the Mounting Location

Pre-assemble the control head to plan the best mounting location.

1. Place 1 metal washer onto each gimbal knob.
2. Place 1 rubber washer onto each gimbal knob.
3. Install the gimbal knobs (with washers) into each side of the control head. Tighten the knobs just enough so you can slide the control head into the gimbal bracket arms.
4. Install the control head into the arms of the bracket mount. Confirm the opening in the gimbal bracket arms faces the rear of the control head. Confirm the ratchets on the bracket and control head fit together.


Assembling the Control Head and Bracket



If you prefer to mount the control head overhead, flip the bracket to the top of the control head. The opening in the gimbal bracket arms must face the rear of the control head.

**NOTE:** Overhead and/or thin panels may require additional hardware (separate purchase required) to securely mount the control head.

Overhead Mount



5. Hand-tighten the gimbal knobs to secure the control head to the gimbal bracket.
6. Place the assembled control head in various locations to determine the best mounting location with the following requirements:
  - a stable, protected surface to protect the control head from excessive wave shock, vibration, and water
  - sufficient space for the control head tilt range
  - visibility during operation, as well as easy installation and removal
  - access above and below the mounting surface to pass the cables through to the control head
  - space for the 1 1/4" (31.75 mm) cable hole located 2" to 4" (50 to 100 mm) behind the chosen mounting location
7. Test route all cables (transducer, power, Ethernet, accessories) to the control head mounting location. Leave enough cable length for the control head tilt range.
8. After you have selected the mounting location, loosen the gimbal knobs and remove the control head from the gimbal bracket.

## 2. Install the Gimbal Bracket

1. Place the gimbal bracket in the chosen position on the mounting surface. Make sure the straight part of the bracket faces forward. The opening in the


gimbal bracket arms must face the rear of the control head. See the illustration **Assembling the Control Head and Bracket** for more information.

2. Mark the four mounting screw locations using a pencil or center punch.
3. Set the gimbal bracket aside. Drill the four mounting screw holes using a 5/32" (4 mm) drill bit.
4. **Cable Hole:** Mark and drill a 1 1/4" (31.75 mm) hole 2" to 4" (50 to 100 mm) behind the bracket. You will use this hole for routing the cables to the control head in another section.
5. Proceed to **Traditional Mount or Overhead Mount**.


### Traditional Mount

1. Place the bracket on the mounting surface aligned with the drilled holes.
2. Fill the mounting holes with marine-grade silicone sealant.
3. Place one flat washer onto each #10 x 1" wood screw. Insert the four screws with washers into the mounting holes and tighten them until they are secure (see the illustration **Installing the Gimbal Bracket**). **Hand-tighten only!**

Installing the Gimbal Bracket



Bracket Hole Pattern Measurements



4. Place the control head back onto the gimbal bracket (see **Plan the Mounting Location** for details). Adjust the control head viewing angle as needed and tighten the gimbal knobs until the assembly is secured. **Hand-tighten only!**

### Overhead Mount

- NOTE:** Overhead and/or thin panels may require additional hardware (separate purchase required) to securely mount the control head.
1. Place the bracket on the mounting surface aligned with the drilled holes. Fill one hole with marine-grade silicone sealant.
  2. Place one flat washer on a #10 x 1" wood screw and install the screw into the hole (see the illustration **Installing the Gimbal Bracket**). Repeat for the remaining three holes.
  3. Tighten each screw until it is secure.
  4. Place the control head back onto the gimbal bracket (see **Plan the Mounting Location** for details). Adjust the control head viewing angle as needed and tighten the gimbal knobs until the assembly is secured. **Hand-tighten only!**

## 3. Connect Power

It is important to review the following information before you start the power installation:

- **Cable Length:** A 6' (2 m) long power cable is included. You may shorten or lengthen the cable using 18 gauge multi-stranded copper wire. See the **Recommended Power Cable Extension Information** table for details.

Recommended Power Cable Extension Information

Extension Length	Wire Gauge
1 to 6 ft	18 AWG
6 to 12 ft	14 AWG
12 to 24 ft	12 AWG

Please consult a U.S. Coast Guard ABYC-approved wire gauge diagram or a certified NMEA Marine Electronics Installer.

- **Power Supply:** The control head must be connected to a 12 VDC power supply using the fuse size and type shown in the **Required Fuse Information** table.

Required Fuse Information (separate purchase required)

Model	Fuse Size	Fuse Type
SOLIX 10	5 A	slow-blow or MDL equivalent
SOLIX 12	5 A	slow-blow or MDL equivalent
SOLIX 15	7.5 A	slow-blow or MDL equivalent

- **Fuse Panel or Battery:** The control head power cable can be connected to the electrical system of the boat at the fuse panel (usually located near the console), or directly to the battery. In order to minimize the potential for interference with other marine electronics, a separate power source (such as a second battery) may be necessary.

**WARNING!** Some boats have 24 or 36 Volt electric systems, but the control head MUST be connected to a 12 VDC power supply.


**WARNING!** Make sure that the power cable is disconnected from the control head at the beginning of this procedure.

**WARNING!** Humminbird® is not responsible for over-voltage or over-current failures. The control head must have adequate protection through the proper selection and installation of the required fuse shown in the **Required Fuse Information** table.


1. Confirm that the power cable is disconnected from the control head.

2. Connect the power cable wires to the fuse panel or battery as follows:

**Fuse Terminal Connection:** Use crimp-on type electrical connectors (not included) that match the terminal on the fuse panel. Attach the black wire to ground (-), and the red wire to positive (+) 12 VDC power. Install the required fuse (as shown in the **Required Fuse Information** table).



**Battery Connection:** Install an inline fuse holder (not included) and the required fuse (as shown in the **Required Fuse Information** table). Attach the black wire to ground (-), and the red wire to positive (+) 12 VDC power.



**NOTE:** For multi-control head installations and troubleshooting information, download the Power Troubleshooting Guide from our Web site at [humminbird.com](#). Also, see the control head operations manual to set the Low Battery Alarm and use Standby Mode to conserve power.

**NOTE:** If you have a trolling motor, it is important to keep the control head power and trolling motor power as separate as possible.

## 4. Route and Connect the Cables

1. **Sonar:** Proceed to your transducer installation guide and follow the instructions to install the transducer.



2. **Accessories (optional):** Install accessories using the guides provided with them.

3. **Ethernet (optional):** Install Ethernet cables and hardware using the Ethernet Installation Guide.


**NOTE:** The installation guides for Ethernet and optional-purchase accessories are available with your product, and they can be downloaded from our Web site at [humminbird.com](#).

4. Route all cables to the control head. Your boat may have a pre-existing wiring channel or conduit that you can follow. Route the cables as far as practical from the antenna cable of VHF radios or tachometer cables to reduce the possibility of interference.

**CAUTION!** Do NOT mount the cables where the connectors could be submerged in water or flooded. If cables are installed in a splash-prone area, it may be helpful to apply dielectric grease to the inside of the connectors to prevent corrosion. Dielectric grease can be purchased separately from a general hardware or automotive store.

5. Pass the cables through the cable hole.

Routing the Cables Behind the Bracket




6. Connect each cable to the appropriate ports on the control head. The ports are labeled, and the connectors are keyed to prevent incorrect installation.

7. Hand-tighten the screw nut on each cable to secure the connection. See the illustration **Routing the Cables Behind the Bracket**.

Cover any unused ports to prevent potential damage.

8. Confirm there is enough cable slack to allow for the control head to pivot through its full tilt range and for connecting or disconnecting the cables. Use nylon cable ties (not included) to secure the cables and create a clean assembly.

**NOTE:** If there is excess cable that needs to be gathered at one location, dress the cable routed from both directions so that a single loop is left extending from the storage location. Doubling the cable up from this point, form the cable into a coil. Storing excess cable using this method can reduce electronic interference.




## 5. Test the System Installation

1. Press the POWER key to turn on the control head. Select **Start Normal Mode**.

When you power on the control head for the first time, use the Setup Guide to configure the unit. After initial setup, these settings can be adjusted from the Home screen > Settings or Setup Guide.

2. Select **Begin Manual Setup**.

To import menu settings from another control head, download the SOLIX Operations Manual from [humminbird.com](#).



- tap to select



- select



3. Select **Angler mode**. Follow the on-screen prompts to configure the unit.

**Angler mode** is the fastest way to configure the control head with less menu settings to get in the way. Use the smart defaults without the need to customize your unit.

**Custom mode** allows you to see more menu settings for a detailed customization of your unit. For details, download the SOLIX Operations Manual from [humminbird.com](#).

4. After the setup is confirmed, press the Home key

5. Select **Settings > Network > System Info**.

**GPS:** Confirm the GPS is listed as **Enhanced Fix** or **3D Fix**. Confirm that a latitude/longitude position is displayed in the **Position** digital readouts section.

**Accessories:** Review the list to confirm accessories are listed as connected. If an accessory is not detected, check cable connections, confirm power is turned on, and review the installation guide. The temp/speed accessory will be detected only if the paddlewheel has moved.

**NOTE:** You can access sensor port settings from **Settings > Network**. To turn on NMEA 0183 output, select **NMEA 0183 sentences**, set the baud rate, etc., select **Settings > Network > NMEA 0183**.

6. Press the Home key.

**Sonar Test:** Test and finalize the transducer installation using the instructions in the transducer installation guide.

8. When the transducer test and installation are completed, the SOLIX control head is ready for on-the-water operation.

Use the **Home screen** to access settings, alarms, views, and tools. The options are determined by the equipment attached to the control head network.

For operations information, see the Quick Start Guide included with your control head and the SOLIX Operations Manual (available for download at [humminbird.com](#)).

## Important Notices

**WARNING!** Disassembly and repair of this electronic unit should only be performed by authorized service personnel. Any modification of the serial number or attempt to repair the original equipment or accessories by unauthorized individuals will void the warranty.

**WARNING!** This device should not be used as a navigational aid to prevent collision, grounding, boat damage, or personal injury. When the boat is moving, water depth may change too quickly to allow time for you to react. Always operate the boat at very slow speeds if you suspect shallow water or submerged objects.

**FCC NOTICE:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**CAUTION!** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Class B Device (Broadcasting and communication equipment for home):

**CAUTION!** This equipment is home use (Class B) electromagnetic wave suitability equipment and to be used at home and it can be used in all areas.

**ENVIRONMENTAL COMPLIANCE STATEMENT:** It is the intention

# SÉRIE SOLIX GUIDE D'INSTALLATION DE LA TÊTE DE COMMANDE

532520-3\_B

## Aperçu

Suivez les directives de ce guide pour monter la tête de commande sur un support à cardan. Nous vous encourageons à lire les directives avant de commencer l'installation afin de prendre connaissance des exigences.

**MATÉRIEL :** En plus du matériel fourni avec la tête de commande, vous avez besoin d'un perceuse électrique et de forets, ainsi que de divers outils à main, tournevis à tête plate, un crayon, des lunettes de sécurité, un masque antipoussières, un agent d'étanchéité à base de silicone de qualité marine, de la graisse diélectrique (facultatif), des câbles de rallonge (facultatif), câbles Ethernet (facultatif), des câbles de l'accessoire (facultatif). Consultez également la section **Connexion de la alimentation électrique** pour voir le type de connexion, fusible, et de l'équipement supplémentaire dont vous aurez besoin pour effectuer l'installation.

**Accessoires et Ethernet :** Les accessoires et l'équipement Ethernet sont disponibles à l'achat sur [humminbird.com](#). Les guides d'installation accompagnent le produit ou il est également possible de les télécharger depuis notre site Web.


**REMARQUE :** Pour l'installation de montage RAM, consultez la section FAQ (Foire aux questions) de notre site Web à l'adresse [humminbird.com](#).

## 1. Préparation de l'emplacement de montage

Assemblez provisoirement la tête de commande et choisissez le meilleur emplacement d'installation.

1. Placez une rondelle métallique sur chaque bouton de cardan.
2. Placez une rondelle en caoutchouc sur chaque molette de cardan.
3. Placez les molettes du cardan (avec rondelles) de chaque côté de la tête de commande. Serrez les molettes juste assez pour pouvoir faire glisser la tête de commande dans les bras du support.
4. Installez la tête de commande dans les bras du support. Confirmer l'ouverture dans les bras du support de cardan face à l'arrière de la tête de commande. Confirmer les cliquets sur le support et la tête de commande ensemble.


Assemblage de la tête de commande et du support



**Si vous préférez monter la tête de commande en hauteur,** faites pivoter le support au-dessus de la tête. L'ouverture dans les bras de support doit faire face à l'arrière de la tête de commande.

**REMARQUE :** Une installation sur une surface en hauteur ou très mince peut nécessiter des accessoires de montage supplémentaires (vendus séparément) afin que la tête de commande soit solidement installée.

Installation en hauteur



5. Avec les doigts, serrez les molettes du cardan pour fixer la tête de commande sur le support.
6. Placez la tête de commande à divers endroits et choisissez le meilleur emplacement de montage avec les conditions suivantes :

- une surface stable et protégée afin de protéger la tête de commande des quantités d'eau, chocs ou remous importants
- un espace suffisant pour pouvoir permettre le pivotement complet de la tête de commande
- une bonne visibilité durant l'utilisation, ainsi que pour faciliter l'installation et le retrait
- un accès sur et en dessous de l'emplacement de montage afin de pouvoir faire passer les câbles jusqu'à la tête de commande
- espace pour le trou de câble de 31,75 mm (1,25 po) situé entre 50 et 100 mm (2 et 4 po) derrière l'emplacement de montage choisi

7. Vérifiez si tous les câbles appropriés (transducteur, alimentation, Ethernet, et accessoires) couvrent bien la distance jusqu'à l'emplacement de montage choisi pour la tête de commande. Laissez suffisamment de longueur de câble pour la gamme d'inclinaison de la tête de commande.

8. Une fois l'emplacement de montage déterminé, desserrez les molettes et retirez la tête de commande du support de cardan.



## 2. Installation du support à cardan

1. Placez le support à cardan à l'emplacement choisi sur la surface de montage. Assurez-vous que la partie droite du support cardan soit orientée vers l'avant. L'ouverture dans les bras de support doit faire face à l'arrière de la tête de commande. Consultez l'illustration **Assemblage de la tête de commande et du support** pour plus d'informations.
2. Marquez la position des vis de montage à l'aide d'un crayon ou d'un poinçon.
3. Mettez le support de cardan de côté. Percez les quatre trous pour les vis de montage, à l'aide d'un foret de 4 mm (5/32 po).
4. **Trou de câble :** marquez et percez un trou de 31,75 mm (1,25 po) à un emplacement qui se trouve entre 50 et 100 mm (2 et 4 po) derrière le support. Ce trou sera utilisé pour acheminer les câbles vers la tête de commande dans une autre section.
5. Procéder à **Montage Classique** ou **Installation en hautier**.

### Montage classique

1. Placez le support de cardan sur la surface de montage, en ligne avec les trous percés.
2. Remplissez les trous au moyen d'un agent d'étanchéité à base de silicone de qualité marine.
3. Placez une rondelle plate sur chaque vis à bois de 25 mm (n° 10 x 1 po). Installez les quatre vis avec les rondelles sur les trous de montage et les serrer jusqu'à ce qu'ils soient sécurisés (voir l'illustration **Installation du support à cardan**). **Serrez les vis à la main seulement!**

Installation du support à cardan



4. Placez la tête de commande sur le support à cardan (pour plus de détails, voir **Préparation de l'emplacement de montage**). Réglez au besoin l'angle de la tête de commande et serrez les molettes du cardan jusqu'à ce que l'assemblage soit solidement maintenu en place. **Serrez les vis à la main seulement!**

### Installation en hauteur

**REMARQUE :** si la surface de montage en hauteur est très mince ou peu propice à l'installation d'un appareil, des accessoires de montage supplémentaires vendus séparément pourraient être nécessaires afin que la tête de commande soit solidement installée.

1. Placez le support sur la surface de montage, en ligne avec les trous percés. Remplissez un trou avec un agent d'étanchéité à base de silicone de qualité marine.
2. Placez une rondelle plate sur une vis à bois de 25 mm (n° 10 x 1 po) et installez la vis dans le trou (voir l'illustration **Installation du support à cardan**). Répétez l'opération sur les trois trous restants.
3. Serrez solidement chaque vis.
4. Placez la tête de commande sur le support à cardan (pour plus de détails, voir **Préparation de l'emplacement de montage**). Réglez au besoin l'angle de la tête de commande et serrez les molettes du cardan jusqu'à ce que l'assemblage soit solidement maintenu en place.

## 3. Brancher l'alimentation

Lisez attentivement les informations suivantes avant de commencer l'installation électrique:

- **Longueur du câble :** Un câble d'alimentation de 2 m (6 pi) est inclus. Il est possible de raccourcir ou rallonger ce câble à l'aide d'un câble multicoupleur en cuivre de calibre 18. Consultez le tableau des **Informations relatives aux rallonges des câbles d'alimentation recommandées** pour plus de détails.

Informations relatives aux rallonges des câbles d'alimentation recommandées

Longueur de la rallonge	Diamètre du fil
0,3 à 1,8 m (1 à 6 pi)	1,02 mm (18 AWG)
1,8 à 3,6 m (6 à 12 pi)	1,63 mm (14 AWG)
3,6 à 7,3 m (12 à 24 pi)	2,05 mm (12 AWG)

Veuillez consulter un diagramme des diamètres de fil de la garde côtière américaine approuvé par l'ABYC ou un installateur de matériel électronique maritime certifié par la NMEA.

- **Système d'alimentation :** la tête de commande doit être connectée à un bloc d'alimentation de 12 V c.c. à l'aide de la taille et type du fusible indiqué dans le tableau des **Requis Fusible Information**.

### Requis Fusible Information (vendus séparément)

Modèle	Taille du Fusible	Type de Fusible
SOLIX 10	5 A	fusible temporisé ou équivalent fusible MDL
SOLIX 12	5 A	fusible temporisé ou équivalent fusible MDL
SOLIX 15	7,5 A	fusible temporisé ou équivalent fusible MDL


- **Tableau à fusibles ou batterie :** on peut brancher le câble d'alimentation de la tête de commande au système électrique du bateau à deux endroits : soit au tableau à fusibles, habituellement situé près de la console, soit directement à la batterie. Afin de réduire les possibilités d'interférence avec d'autres systèmes électroniques marins, il pourrait s'avérer nécessaire d'utiliser une autre source d'alimentation (telle une seconde batterie).

**AVERTISSEMENT !** Certains bateaux sont munis de systèmes électriques de 24 V ou 36 V, mais la tête de commande DOIT être branchée à un bloc d'alimentation de 12 V c.c.

**AVERTISSEMENT !** Assurez-vous que le câble d'alimentation n'est pas branché à la tête de commande au début de cette procédure.

**AVERTISSEMENT !** Humminbird ne garantit pas le produit contre les surtensions et les surintensités. La tête de commande doit disposer d'une protection suffisante; installer de façon adéquate du fusible requis indiqué dans le tableau des **Requis Fusible Information**.

1. Assurez-vous que le câble d'alimentation n'est pas branché à la tête de commande.
  2. Connectez les câbles d'alimentation au tableau à fusibles ou à la batterie comme suit :
- Connexion au tableau de fusibles :** utilisez des connecteurs électriques à sertir (non inclus) qui conviennent au raccord du tableau à fusibles. Branchez le fil noir à la masse (-) et le fil rouge à l'alimentation (+) de 12 V c.c. Installez le fusible requis (comme indiqué dans le tableau des **Requis Fusible Information**).



**Connexion à la batterie :** Installez un porte-fusible (non inclus) et le fusible requis (comme indiqué dans le tableau des **Requis Fusible Information**). Branchez le fil noir à la masse (-) et le fil rouge à l'alimentation (+) de 12 V c.c.



**REMARQUE :** Pour des informations relatives au dépannage et aux installations de plusieurs têtes de commande, téléchargez le guide de dépannage relatif à l'alimentation électrique depuis notre site Web sur [humminbird.com](#). Consultez également le guide d'utilisation de la tête de contrôle pour définir l'alarme source d'alimentation faible et utiliser le mode Veille afin d'économiser de l'énergie.

**REMARQUE :** Si vous avez un moteur de pêche à la traîne, il est important de garder la puissance de la tête de commande et la puissance du moteur de pêche à la traîne aussi séparées que possible.

### 4. Acheminement et connexion des câbles

1. **Sonar :** Passez au guide d'installation du transducteur et suivez les instructions détaillées.
2. **Accessoires (en option) :** Installez les accessoires à l'aide des guides d'installation fournis.
3. **Ethernet (en option) :** Installez les câbles Ethernet et la quincaillerie en vous aidant du guide d'installation Ethernet.




- REMARQUE :** Les guides d'installation Ethernet et des accessoires en option sont fournis avec le produit et peuvent être téléchargés depuis notre site Web [humminbird.com](#).
4. Acheminez tous les câbles vers la tête de commande. Il se peut que votre bateau soit déjà muni d'une canalisation ou conduite de câblage que vous pouvez utiliser pour acheminer les câbles. Veillez à garder le câble le plus à l'écart possible de tout câble d'antenne de radio VHF ou de câble de tachymètre afin de limiter les possibilités d'interférence.

**MISE EN GARDE !** Ne PAS monter les câbles dans un endroit où les connecteurs pourraient être submergés. Si les câbles sont installés dans une zone où des éclaboussures sont possibles, il est préférable d'appliquer de la graisse diélectrique sur l'intérieur des connecteurs pour éviter la corrosion. Il est possible d'acheter la graisse diélectrique séparément dans une quincaillerie ou un magasin d'équipement automobile.

5. Faites passer les câbles dans le trou de câble.

### Acheminement des câbles derrière le support




6. puis branchez-les sur les connecteurs appropriés de la tête de commande. Les ports sont étiquetés et les connecteurs de câbles sont également marqués afin d'éviter toute erreur d'installation.
7. Serrez les écrous de vis sur les câbles à la main pour sécuriser les connexions. Voir l'illustration **Acheminement des câbles derrière le support**.

Tous les ports non utilisés doivent être recouverts d'un cache afin d'éviter de les endommager.

8. Assurez-vous que les câbles aient assez de mou pour permettre à la tête de commande de pivoter entièrement et pour leur branchement/débranchement. Utilisez des attaches de câble en nylon (vendues séparément) pour fixer les câbles et créer un assemblage net.

**REMARQUE :** Si le câble est un peu long et que vous devez ranger l'excédent quelque part, placez le câble que vous aurez tiré des deux directions de façon à ne former qu'une seule boucle (comme c'est montré dans l'illustration). Doublez le câble à partir de ce point et enroulez-le en spirale. Le fait de ranger l'excès de câble de cette manière peut contribuer à réduire les interférences électroniques.




## 5. Essais de l'installation du système

1. Appuyez sur la touche de mise en marche pour mettre la tête de commande en marche. Sélectionnez **Démarrer le mode normal**.

Lorsque vous allumez la tête de commande pour la première fois, consultez le guide de configuration pour configurer l'appareil. Après la configuration initiale, les réglages peuvent être modifiés sous Accueil > Réglages ou Guide de Configuration.

2. Sélectionnez **Lancer la configuration manuel**.

Pour importer les réglages de menu d'une autre tête de commande, téléchargez le guide d'utilisation SOLIX depuis [humminbird.com](#).



3. Sélectionnez le **mode Pêcheur**. Suivez les invites à l'écran pour configurer l'appareil.

Le **mode Pêcheur** est le moyen le plus rapide de configurer la tête de contrôle avec moins de paramètres de menu pour obtenir de la manière. Utilisez les valeurs par défaut intelligentes sans avoir besoin de personnaliser votre unité.

Le **mode Personnalisé** vous permet de voir plus de paramètres de menu pour une personnalisation détaillée de votre appareil. Pour plus de détails, téléchargez le guide d'utilisation SOLIX depuis [humminbird.com](#).

4. Lorsque la configuration est confirmée, appuyez sur la touche Accueil

5. Sélectionnez Réglages > Réseau > Info système.

**GPS :** Assurez-vous que le réglage Type de position affiché est **Améliorée** ou **3D**. Assurez-vous que les valeurs de latitude/longitude sont affichées dans la section des **Position** de indicateurs numériques.



HUMMINBIRD

# APEX™ / SOLIX®

## QUICK START GUIDE

### Power On/Off

**Power On/Off:** Press and hold the POWER key.

**Power Off:** During operation, tap the top, right corner of the status bar and select Power Off.



### First Time Setup

When you power on the control head for the first time, use the Setup Guide to configure the unit. These settings can be adjusted from the Home screen later.


1. Tap to select **Begin Manual Setup**.



Or use the Joystick and CHECK key to select.



2. Select **Angler mode** [basic settings and menu functions for easy operation] or **Custom mode** [all settings and menu functions for complete customization]. Follow the on-screen prompts to configure the unit.



 **NOTE:** For additional information, download the APEX/SOLIX Operations Manual from our Web site at [humminbird.com](http://humminbird.com).

 **NOTE:** See the **Key Functions** page at the back of this guide for more helpful tips.

## The Home Screen


The Home screen is the main control center for your control head. Use the Home screen to access control head settings, navigation data, views, alarms, and other tools.




Press the HOME key to open the Home screen from any view.

- Tools, views, and widgets available on the Home screen are determined by the equipment attached to the control head network.
- Pair your Bluetooth®-capable control head and mobile phone to receive text message and phone call alerts on your Home screen.
- The Home screen wallpaper can be customized using the Images tool.
- The APEX Home screen and tool menus includes an additional Data Dashboard that displays your connected phone, control head system information and standard data box readouts.

### APEX Home Screen



## SOLIX Home Screen



## ► Select a Tool, Widget, View, or Main Menu

Use the touch screen, Joystick, or the ENTER key to make selections.



Tap to Select

OR




Select




Open

## ► Adjust a Menu Setting

Drag the slider, or press and hold the slider.




Turn the Rotary dial, or press and hold the ENTER key.



## ► Close a Menu

☒ Tap the Back icon to go back one level.

☒ Tap the X icon to close a menu.




Press the EXIT key to close a menu or go back one level. Press and hold the EXIT key to close all menus.



## ► Tips for Using the Status Bar

The status bar is located at the top of the screen.




Tap the view name or press the MENU key to open the X-Press Menu for the on-screen view.

Tap the status bar or press the POWER key to open the Power X-Press Menu.


## Display a View from the Views Tool

Use the touch screen or the Joystick to open a view from the Views tool.



## Display a View from the Favorite Views Widget

1. Tap the Favorite Views widget in the side bar, or press the Rotary dial.
2. Tap a view, or turn the Rotary dial and press the ENTER key.



tap to close the Favorite Views widget

## Edit the On-Screen View (X-Press Menu)

The X-Press Menu displays menu options for the on-screen view, the selected pane, and the operation mode.


1. **Single-Pane View:** Tap the view name in the status bar, or press the MENU key.

**Multi-Pane View:** Tap a pane, or press the PANE key to select a pane. Press the MENU key.

2. Select **[Pane Name] Options > Preferences** to change the appearance of the view.

Select **[Pane Name] Options > Overlays** to display or hide information on the view.

Select **View Options > Data Overlays** to display data readouts on the view.



OR





Tap to Select a Pane and the Menu

Press the PANE key to Select a Pane

Press the MENU key


## Activate the Cursor

Tap a position on the view, or move the Joystick.  
To open the Cursor menu, press and hold a position.



## Zoom In/Zoom Out

Pinch out to zoom in, pinch in to zoom out, or press the +/- ZOOM keys.




## Set Up Humminbird® Charts: Set the Water Level Offset

When you start your trip for the day using a Humminbird CoastMaster™ or LakeMaster® chart card, it is important to note if the water level is higher or lower than usual. For example, if the digital depth on your control head is showing 3 feet less than the related depth contour for your location, set Water Level Offset to -3 feet.

1. With a Chart View displayed on-screen, tap Chart in the status bar, or press the MENU key once.
2. Select Water Level Offset.
3. Tap the on/off button, or press the ENTER key, to turn it on.
4. Press and hold the slider, or turn the Rotary dial, to adjust the setting.



**NOTE:** A Humminbird CoastMaster or LakeMaster chart card must be installed and selected as the chart source to enable this feature.



OR



Tap to select a menu.  
Press and drag the slider to  
adjust the menu setting.

Press the MENU key

Turn the Rotary dial to  
adjust the menu setting.

**NOTE:** To apply depth colors, depth highlight range, etc., go to the Chart X-Press Menu > Humminbird Settings. See your operations manual for details.

## Mark Waypoints


Open the Mark Menu and select Waypoint, or press the MARK key **twice**.

If the cursor is not active, the waypoint will be marked at the boat position. If the cursor is active, the waypoint will be marked at the cursor position.



## Activate Man Overboard (MOB) Navigation


As soon as you know you have a man overboard, **press and hold the MARK/MAN OVERBOARD key**. See your operations manual for details.



**NOTE:** To end navigation, press the GO TO key and select Cancel Navigation.

## Start Quick Route Navigation (touch screen)

1. **Open the Cursor Menu:** Press and hold a position on the chart.
  2. Select Go To.
  3. Select Quick Route.
  4. Tap the chart in the positions where you want to mark a route point.
- Undo Last Route Point:** Tap the Back icon.
- Cancel Route Creation:** Tap the X icon.
5. To start navigation, tap the check icon in the status bar.
- Cancel Navigation:** Tap Chart in the status bar. Select Go To > Cancel Navigation.



Tap to Mark  
Route Points

## Start Quick Route Navigation (keypad)


1. Press the GO TO key.
2. Select Quick Route.
3. Use the Joystick to move the cursor to a position or waypoint. Press the Joystick to mark the first route point.
4. Repeat step 3 to connect more than one route point.

**Undo Last Route Point:** Press the EXIT key once.

**Cancel Route Creation:** Press and hold the EXIT key.

5. To start navigation, press the ENTER key.

**Cancel Navigation:** Press the GO TO key. Select Cancel Navigation.



Open Go To Menu



Move Cursor Position



Mark Route Points



Start Navigation

## **Pair a Phone with the Control Head**

Use the following instructions to pair a mobile phone to the control head using **Bluetooth** wireless technology. [Available with **Bluetooth** supported Humminbird products and mobile devices only. Wifi or data connection required.]

### **Enable Bluetooth on the Phone**

1. Open the Settings menu on your phone.
2. Select Bluetooth.
3. Select On.

### **Pair the Phone with the Control Head**

1. Press the HOME key.
2. Select the **Bluetooth** tool.
3. Under Phone Bluetooth, select Settings.
4. Select Connect Phone.
5. Follow the on-screen prompts to complete the pairing process.
6. Check your phone. When prompted, tap Pair on your phone.
7. Press Confirm on your control head.

Upon successful pairing, the control head will be listed as connected under the phone's Bluetooth menu.

### **Change the Phone Bluetooth Notification Settings on the Control Head**

1. Under the Phone Bluetooth menu, select Settings.
2. Select Text Message Alerts or Phone Call Alerts.  
Tap to select an alert format. To turn off notifications, select off.
3. **Turn Sounds On/Off:** Select Sounds. Select on or off.

### **Change the Phone Bluetooth Notification Settings on the Phone**

1. **Apple iOS:** Open the phone's Bluetooth menu, and select the control head under My Devices.  
**Google Android:** Open the phone's Bluetooth menu, and next to the control head's name under Paired Devices, select Settings.
2. **Apple iOS:** Turn on Show Notifications.  
**Google Android:** Turn on Message Access.

## Managing your Humminbird Unit

### Register your Humminbird

Register your product(s) and sign up to receive the latest Humminbird news, including software updates and new product announcements.

1. Go to our Web site at [humminbird.com](http://humminbird.com), and click Support > Register Your Product. Follow the on-screen instructions to register your Humminbird product.

### Download the Operations Manual

1. Go to our Web site at [humminbird.com](http://humminbird.com), and click Support > Manuals.
2. **APEX:** Under APEX Series, select APEX Series Product Manual.  
**SOLIX:** Under SOLIX Series, select SOLIX Series Product Manual.

### Update Software

It is important to keep your control head and accessory software up to date. You can update software using an SD or microSD card [depending on your APEX/SOLIX model] or by using **Bluetooth** wireless technology and our FishSmart™ App. See your operations manual for complete details about updating software.

- **Before you install software updates,** export your menu settings, radar settings, and navigation data from your control head to an SD or microSD card. Copy your internal screen snapshots to an SD or microSD card.
- **To check your current software version,** press the HOME key and select Settings > Network > System Info.
- **To update software with an SD or microSD card,** you will need a formatted SD card or microSD card with an adapter. Visit our Web site at [humminbird.com](http://humminbird.com) and click Support > Software Updates. Select the software update for your control head model and follow the on-screen instructions to save the software file to the card. Then, power on the control head and install the SD card in the card slot. Follow the on-screen prompts to confirm the software update.
- **To update software with FishSmart,** visit our Web site at [humminbird.com](http://humminbird.com) and click Learn > FishSmart App. Use the FishSmart App to download and push software updates directly to your Humminbird control head or accessory. [Available with **Bluetooth** supported Humminbird products and mobile devices only. Wifi or data connection required.]



**NOTE:** Your control head must already be running software release 3.110 or higher to support this feature.

Key	Key Functions
	Press the <b>POWER key</b> to power on the control head. During operation, press the power key to open the Power X-Press Menu. Press and hold the power key to power off the control head.
	Press the <b>ENTER key</b> to start a command or turn on a setting. The ENTER key also opens the Info menu and the Cursor menu.
	Press the <b>EXIT key</b> once to close a menu, close a dialog box, turn off an alarm, or exit Cursor mode. Press and hold the EXIT key to close all menus at once.
	Move the <b>Joystick</b> to select a view, tool, or menu. Press the Joystick to open your selection. The Joystick is also used to move the cursor across the view and pan 2D/3D chart views.
	Turn the <b>Rotary dial</b> to adjust menu settings. With a view displayed on-screen, press the Rotary dial to open the Views bar.
	<b>GO TO/Screen Snapshot key:</b> Press this key once to open the Go To menu for navigation functions. Press and hold this key to save the screen image.
	Press the <b>PANE key</b> to open the View Options menu or to select a pane in a multi-pane view.
	<b>MARK/MAN OVERBOARD key:</b> Press and hold this key to start Man Overboard Navigation. To mark waypoints, press this key twice.
	Press the <b>HOME key</b> to display the Home screen. The Home screen allows you to access settings, alarms, views, and tools for the control head.
	For a closer view, press the <b>ZOOM IN [+]</b> key. For a wider view, press the <b>ZOOM OUT [-]</b> key. Press and hold the ZOOM OUT [-] key to zoom out all the way.
	<b>MENU key:</b> To open the X-Press Menu for the on-screen view and operation mode, press the MENU key once. To open the Main Menu [Settings tool], press the MENU key twice.

## Notes

## Contact Humminbird Technical Support

---

Contact Humminbird Technical Support in any of the following ways:

Toll Free: **[800] 633-1468**

International: **[334] 687-6613**

E-mail: **service@humminbird.com**

Shipping: **Humminbird**  
**Service Department**  
**678 Humminbird Lane**  
**Eufaula, AL 36027 USA**

---

Our Web site, **humminbird.com**, offers in-depth information about all things Humminbird, along with technical support, product manuals, software updates, and a robust FAQ section.

For more great content, visit:



[Facebook.com/HumminbirdElectronics](https://www.facebook.com/HumminbirdElectronics)



[@humminbirdfish](https://twitter.com/@humminbirdfish)



[Instagram.com/humminbirdfishing](https://www.instagram.com/humminbirdfishing)



[YouTube.com/humminbirdtv](https://www.youtube.com/humminbirdtv)

