
Davise

ARTIFICIAL horizon



ASSEMBLY INSTRUCTIONS

To assemble, lift the lid from the horizon bowl and remove the side pieces and horizon shades. Fill the bowl with water or a more viscous liquid. The depth of the liquid is not important to 25° , the accuracy of your sextant reading. However, if the sun is close to the horizon, the bowl will need to be nearly filled in order to obtain a reading.

Now erect the side pieces by fitting them onto the sides of the bowl. These hold the horizon shades and also act as a windbreak to prevent ripples on the water surface.

Next choose the horizon shade arrangement to fit your needs. The two plastic shades, when used together, darken the sun's reflection so that the reflection may be observed directly without use of your sextant's horizon shades.* However, if the sun is sufficiently low on the horizon, if you are taking your shots at night, or if you prefer to use your sextant's horizon shades, you may use any combination with the glass windows included.

*CAUTION: Looking at the sun's reflecttion without sufficiently shading the image can cause eye damage.

Reads 50° OPERATING INSTRUCTIONS

Ray from Sun

To operate the Artificial Horizon, first fill the bowl with water or a more viscous liquid and place it on a table or on the ground in such a position that the sun is directly facing one end. This can be done by moving the Artificial Horizon until it casts a shadow only at the opposite end—the sides and end facing the sun being shadow free.

Now stand or sit in such a position that you can see the sun's reflection on the liquid surface. Sight through your sextant until you have placed this reflection where the real horizon would normally appear on your instrument.

(over)

Move the index arm of your sextant until the double-reflected image of the sun on the mirrors of your sextant is brought into coincidence with the reflection on the liquid.

In the case of the sun or moon, the bottom of the double-reflected image is brought into coincidence with the top of the image on the liquid for a lower limb observation. For an upper limb observation, the opposite sides are brought into coincidence. If one image is made to cover the other, the observation is of the center of the body.

When the observation has been made, apply the index correction. Then take half the remaining angle and apply all other corrections except dip (height of eye) correction, since this is not applicable.

Since the Artificial Horizon doubles your sextant reading, the maximum altitude which can be observed is equal to one half the maximum arc graduation on your sextant. Thus, observations of the sun should normally be planned for morning or evening, as there may be several hours near noon when the sun will be too high.

Davise

View other marine cables made by Davis Instruments on our website.