



# SEAL-TITE® BOOTS

## GENERAL INFORMATION

1. **NOTICE:** For installation by a qualified electrician in accordance with national and local electrical codes and the following instructions.
2. **CAUTION: RISK OF ELECTRIC SHOCK. Disconnect power before installing. Never wire energized electrical components.**
3. Check that the device's type and rating are suitable for the application.

## INSTRUCTIONS

1. The cone end portion of the boot must fit tightly around the cable. Depending on the cable diameter it may be necessary to cut the cone end of the boot at one end of the diameter rings for the proper fit.

When the cable diameter is greater than ring diameter "A", cut off flush with next larger diameter ring.



2. Slide the boot approximately 8 inches up the cable.
3. Wire the device to the cable following the instructions provided with the device.
4. Slide the boot over the device. Be sure device is pushed all the way back into the boot.

## BOOTS WITH THREADED SEALING RING

5. Place the threaded ring over one edge of the boot's lip. Work the remaining lip into the ring.